



# Connects2Vision

User Manual

**CAM-NS1-RT**

OEM Reverse Camera Retention Interface  
For Nissan Vehicles

---

## APPLICATION:

### Nissan

Navara	2005 - 2014
Note	2008 - 2012
Pathfinder	2007 - 2012
Qashqai	2010 - 2014
X-Trail	2011 - 2014

---

## DISCLAIMER:

### Prior to Installation

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure you use the correct tools to avoid damage to the vehicle or product.

***Connects2 can not be held responsible for the installation of this product.***

### Technical Support

Connects2 want to provide a fast and suitable resolution should you encounter any technical issues. With this in mind, when contacting Connects2, try to provide as much Information as possible. This will speed up the process and help us to help you.

**Please use our dedicated online technical support centre: [support.connects2.com](http://support.connects2.com)**

- OEM Camera Retention Lead
- Instructions

## INSTALLATION

---

1. Connect the yellow RCA connector from the interface to the camera input on the rear of the aftermarket head unit
2. Connect the white connector from the interface to the vehicle harness
3. Connect the Red flying wire to the vehicle's Reverse Signal feed
4. Connect the Black flying wire to Ground



Subscribe to our YouTube Channel for installation guides and tips... [www.youtube.com/connects2](http://www.youtube.com/connects2)