

Installation Instructions

1. The Honda Civic with original navigation has CAN wires in a different connector to those cars without navigation.
2. Cut the pink and Pink/Black wires off the 20 way grey connector on the PAC RP4-HD11 harness. Leave the Red , white and white black in place .
3. Identify the 24 pin grey connector shown below in the car. Join the Pink to the Pinkish Brown cable shown below (pin 19), and the Pink/Black to the Blue/Silver (pin7)
4. For phone answer and reject functions connect the White/ green wire under the steering column to pin 3 of the 16 way connector (as per the PAC instructions)
- 5.

