



TE-GTGCHD (CCD) / TE-GTGC (CMOS)

**CHEVY SILVERADO/GMC SIERRA 1500
(2007-2013)**

**CHEVY SILVERADO/GMC SIERRA
2500/3500 (2007-2014)**

Replacement Tailgate Handle with Camera

Removal and Installation Instructions

Tools Needed: 13mm wrench/13mm socket
and ratchet

I. Start by lowering the tailgate. On the inside of the tailgate you will see three bolts. Remove the two bolts that are side by side directly in front of you. Those bolts secure the tailgate handle to the tailgate.

II. Now close tailgate, carefully lift the factory tailgate handle out and away from the tailgate.

III. Now that the handle is out of the tailgate, you will have to swap the locking mechanism out of the old handle to the new one.

IV. Route the backup camera's wires through the tailgate handle's opening and through the tailgate itself.

NOTE: Avoid any areas that can pinch the tailgate camera harness.

V. Remove taillight and splice the red power wire from the camera's harness into the reverse light's 12v positive wire. This will trigger the camera to turn on when vehicle is placed in reverse. Attach the black ground wire to a metal non-painted surface.

VI. Wires can now be fully routed from the tailgate to the cab of the truck and to a video source. The Yellow RCA will plug into the input of your video source; the Red wire goes to the rear camera input trigger wire on your video source.

NOTE: Test to make sure video is working before securing new handle.

NOTE: If desired parking lines can be removed by attaching the green wires together.

VII. Carefully replace new tailgate handle in tailgate and secure the handle using the two bolts that were previously removed.



1.800.221.0932

www.iBeamUSA.com

460 Walker Street, Holly Hill, FL 32117