




WIRING DIAGRAM LDS-VWGF-CP



DIP SWITCH SETTING
(After changing the dip code,press "reset"or power-on again)

DIP	S/W	STATUS	FUNCTION
PIN 1	OFF/ON		7 inch / 5.8inch
PIN 2	OFF/ON		NG/Touch point coordinate correction,and then turn"OFF"
PIN 3	OFF/ON		Close front view camera/Open front view camera
PIN 4	OFF/ON		Reversing gridline/Enable 360 panoramic
PIN 5	OFF/ON		NG/NG
PIN 6	OFF/ON		Rear view camera CVBS input / RGB input
PIN 7	OFF/ON		NG / NG
PIN 8	OFF/ON		Aftermarket rear view CAM/Original rear view CAM



REMARK:Please keep in the AUX interface when switch the CarPlay interface

- 1) Long press and hold "MENU" button to switch MENU, long press"MENU" button again,exit the switch MENU.
- 2)Short press "SOUND" button to open "Siri".
- 3)Other functions use touch screen to control it.