



## Mounting direction:

A very important step is the placement and mounting direction of the XBB PowerUnit™. When installing XBB PowerUnit™ in the engine compartment it is very important to mount the XBB PowerUnit™ with the socket pointing downwards. XBB PowerUnit™ has IP 53 protection only when mounted with the socket downwards.

## Note!

Avoid using water to wash the surrounding parts and XBB PowerUnit™. If you must use water or pressure washer, please remove XBB PowerUnit™ from the relay socket before using water. Placement from the XBB Dongle™ should be as short as possible. Even though both XBB PowerUnit™ and XBB Dongle™ have a relatively high output power, the signal can be disturbed due to encapsulation depending on vehicle construction and/or damping materials.






	<u> </u>	Innoware Development AB		
	Innoware Development	Hyttvägen 13		
		733 38 SALA		
	FILNAMN	DATO 2021-02-04	Ver 1.0	SCHEMANUMMER
8	CHEM AN AM N	rit JB		

## Mounting direction:

A very important step is the placement and mounting direction of the XBB PowerUnit™. When installing XBB PowerUnit™ in the engine compartment it is very important to mount the XBB PowerUnit™ with the socket pointing downwards. XBB PowerUnit™ has IP 53 protection only when mounted with the socket downwards.

## Note!

Avoid using water to wash the surrounding parts and XBB PowerUnit™. If you must use water or pressure washer, please remove XBB PowerUnit™ from the relay socket before using water. Placement from the XBB Dongle™ should be as short as possible. Even though both XBB PowerUnit™ and XBB Dongle™ have a relatively high output power, the signal can be disturbed due to encapsulation depending on vehicle construction and/or damping materials.



	Innoware Development AB			
Innoware Development	Hyttvägen 13			
De velopi nem	733 38 SALA			
FILNAMN	DATO 2021-02-04	Ver 1.0	SCHEMANUMMER	
SCHEMANAMN	rit JB			